

211 Peach Way
Columbia, MO
573-474-7881

A-1 *Party and Event* **RENTAL**

VocoPro VHF-3005 Dual Wireless Handheld Microphone Operating Instructions



1. Plug main unit into power supply and press the power button on the front.
2. Turn volume down on the unit and the speakers you are using.
3. Attach main unit to speaker source using the 2 cords provided in the case.
4. Turn Mic on by sliding the button on the Mic up.
5. Turn volume on main speaker unit and Mic Unit to test sound.
6. To mute mic, move button to middle selector.
7. Sing your heart out!

***Extra batteries are provided in the case if needed.

Feel free to give us a call if more problems persist so we can help you get it working properly!