

211 Peach Way
Columbia, MO
573-474-7881

A-1 *Party and Event* RENTAL

Samson CR88 Wireless Handheld and Wireless Lapel Microphone Operating Instructions



1. Plug main unit into power supply and press the power button on the front.
2. Turn volume down on the unit and the speakers you are using.
3. Attach CR88 unit to speaker source using the cord provided in the case.
4. Turn Mic on by holding the button on the Mic until it turns green. Once this is done, the green "Ready" light on the front of the machine will light up and the unit is synced with the mic.

Proceed to step 6 if this is the case.

5. To sync Mic and Unit, unscrew body of Mic (handheld) or flip down cover (lapel) to reveal IR sensor. Turn mic on by holding power button. Hold the select button on main unit until it flashes. Once done, the ready light should light up in a couple of seconds.
6. To mute Mic, push the power button once and it will turn red
7. Turn volume on main speaker unit and Mic Unit to test sound.
8. Sing your heart out!

****Extra batteries are provided in the case if one dies.

Feel free to give us a call if more problems persist so we can help you get it working properly!