




DANCE FLOOR





DANCE FLOOR

LAYOUT DEPICTS ONE, 15'X15' FLOOR.
LAY EACH ROW FROM LEFT TO RIGHT.



COMPONENTS: 23 FULL PANELS, 4 HALF PANELS, 16 FULL EDGES,
4 HALF EDGES, 2 LEFT CORNERS, AND 2 RIGHT CORNERS.