





MICROPHONES



MICROPHONES

SINGLE WIRELESS & LAPEL:

1. Plug main unit into power supply and press the power button on the front.
2. Turn volume down on the unit and the speakers you are using.
3. Attach CR88 unit to speaker source using the cord provided in the case.
4. Turn mic on by holding the button on the mic until it turns green. Once this is done, the green "Ready" light on the front of the machine will light up and the unit is synced with the mic.
Proceed to step 6 if this is the case.
5. To sync mic and unit, unscrew body of mic (handheld) or flip down cover (lapel) to reveal IR sensor. Turn mic on by holding power button. Hold the select button on main unit until it flashes. Once done, the ready light should light up in a couple of seconds.
6. To mute mic, push the power button once and it will turn red
7. Turn volume on main speaker unit and mic unit to test sound.

DUAL WIRELESS:

1. Plug main unit into power supply and press the power button on the front.
2. Turn volume down on the unit and the speakers you are using.
3. Attach main unit to speaker source using the 2 cords provided in the case.
4. Turn mic on by sliding the button on the mic up.
5. Turn volume on main speaker unit and mic unit to test sound.
6. To mute mic, move button to middle selector.

* extra batteries are provided in the case if needed *