




POPCORN



POPCORN

INSTRUCTIONS:

1. Turn on two switches.
2. Allow kettle to warm up for approximately 5 minutes.
3. Empty popcorn, butter, and oil packet into kettle.
4. Pull lid closed to prevent stray kernels. (Lid is held in place by magnet directly above the kettle.)
5. While corn is popping, keep front operator doors slightly ajar to prevent fogging. Keep hopper door at "out" position to aid in catching stray popcorn.
6. Allow corn to pop until popping ceases, usually when 3-4 seconds lapse between pops.
7. Then pour remaining popped corn from kettle by rotating handle clockwise 1/3 turn and pulling downward.
8. Turn kettle switch to OFF position when finished preparing popcorn; power or light switch may remain ON to display and heat popcorn.
9. KETTLE WILL BE HOT! Please be sure to avoid direct contact with the kettle during the popping process.

For return, please note that the machine must be clean or a cleaning fee will added.